

E E **Expert Analysis Application Quick Reference** Card

## **Overview of Menu Options**

This guide provides an overview of most options in the Sniffer analysis application's menus. These illustrations show the analysis application's factory defaults. Choose the Use Defaults command to restore these values at any time.







Will vary depending on network.
Internetwork Analyzer (WAN/Synchronous).

Capture Filters Menus

**Expert Analysis Application Quick Reference Card** 

Main Menu


Expert Analysis Application Quick Reference Card


**Second Level Third Level Fourth Level** Buffer=55Ø4K EXP◆ Frame size -32 bytes 64 bytes 128 bytes 256 bytes 512 bytes Whole frame Expert mode Classic mode Screen format-Show frame counts Show Kbyte counts Show NW usage Linear bar scale Log bar scale Expert window -Name width = 15 ◀ Individual counts From <Ethernet>◀ Pair counts Skulines -1 second update 1 minute update 1 hour update


Sniffer Network Analyzer for Ethernet only (not present on DSS).

Menus


Capture







DSS only. Internetwork Analyzer (WAN/Synchronous). Token ring only.



Sniffer Network Analyzer only (not present on DSS). Internetwork Analyzer (WAN/Synchronous). FDDI only. Token ring only.

Menus

and Options

Files



## **CORPORATE HEADQUARTERS**

NETWORK GENERAL CORPORATION 4200 BOHANNON DRIVE MENLO PARK, CA 94025 USA TEL: (415) 473-2000

## **NETWORK GENERAL EUROPE**

BELGICASTRAAT 4 1930 ZAVENTUM, BELGIUM TEL: 32 (2) 725-6030

## NETWORK GENERAL CANADA, LTD.

9225 LESLIE STREET, UNIT #7 RICHMOND HILL, ONTARIO L4B 3H6 CANADA TEL: (905) 882-7905